

BASECAMP

Replacement Parts Manual



RER
Innovative
Product
Award

RER
Best New
Light Tower
Award




DISASTERS
EXPO USA
INNOVATIVE
TECHNOLOGY
AWARD



Table of Contents

ITEM NAME	PAGE NUMBER
EXTERIOR HARDWARE - PASSENGER SIDE	3
EXTERIOR HARDWARE - DRIVERS SIDE	4
INTERIOR COMPONENTS	5
INTERIOR COMPONENTS - CONT'D	6
ENGINE SKID ASSEMBLY	7
ENGINE SKID ASSEMBLY - CONT'D	8
ELECTRICAL PANEL - EXTERIOR	9
ELECTRICAL PANEL - INTERIOR	10
LIGHT TOWER	11
LIGHT MAST WIRING DIAGRAM	12
EXTERIOR FUEL SOURCE CONNECTION	13
TRAILER WIRING DIAGRAM	14
FILTERS	15


EXTERIOR HARDWARE - PASSENGER SIDE



REF	PART	DESCRIPTION
1	TIP-3026	TRI COLOUR BEACON LIGHT
2	TI1-0134	LIFTING EYE
3	TIP-1011	EXHAUST OUTLET ASSEMBLY
4	TI1-0037	RADIATOR FILL ACCESS COVER
5	TIP-1025	DOOR HINGE (RIGHT HAND)
6	TIP-1124	DOOR LATCH
7	TI1-0192	FENDER
8	TI1-S010	OUTRIGGER TUBE
9	TIP-1004	AXLE, COMPLETE WITH HUBS
10	TI1-0095	DUCTING STORAGE POST
11	TIP-1024	DOOR HINGE (LEFT HAND)
12	TI1-0177	ELECTRICAL DOOR ASSEMBLY

REF	PART	DESCRIPTION
13	TI1-S023	ROOF PANEL
14	TI1-0028	PASSENGER SIDE DOOR
15	TI1-S043	CONTAINMENT TANK (TRAILER FRAME)
16	TI1-0026	DOOR SILL
17	TI1-0030	FRONT PANEL
18	TIP-3023	ANTENNA
19	TI1-0138	BEACON MOUNT PLATE
20	TIP-1009	EXHAUST RAIN CAP
21	TI3-0012	WHEEL CHOCK HOLDER
22	TIP-1027	WINDOW GLASS
23	TIP-1129	RUBBER FLAP


EXTERIOR HARDWARE - DRIVERS SIDE



REF	PART	DESCRIPTION
1	TI2-023	MAST ADAPTER
2	TI1-0170	INTAKE COVER
3	TI1-0165	FUEL DOOR
4	TIP-3003	LICENSE PLATE LIGHT
5	TIP-1083	TAIL LIGHT
6	TIP-1082	RED MARKER LIGHT
7	TIP-1081	AMBER MARKER LIGHT

REF	PART	DESCRIPTION
8	TIP-1018	DUCTING CLAMP
9	TI1-S008	12" DUCT CHUTE
10	TIP-1012	1-1/2" NPT DRAIN PLUG
11	TI1-0031	DRIVERS SIDE DOOR
12	TI1-0027	BACK PANEL
13	TI1-0029	DUCT CHUTE PANEL
14	TIP-1125	FUEL DOOR HINGE


INTERIOR COMPONENTS



REF	PART	DESCRIPTION
1	TI1-0098	INLET CAGE
2	TI1-0020	COIL BANK COVER
3	TIP-1006	HEATING ELEMENT
4	TI1-0032	DOOR LATCH
4a	TIP-1131	SQUARE DOOR LATCH BOLT
5	TIP-1016	DOOR SWITCH
5b	TIP-1015	DOOR SWITCH MAGNET

REF	PART	DESCRIPTION
6	TIP-1122	FUEL TANK VENT
7	TIP-1022	FUEL LEVEL SENSOR
8	TIP-3067	RTD SENSOR
9	TIP-1020	4" CAMLOCK
10	TIP-1021	FUEL CAP
11	TIP-1130	FUEL DOOR MAGNET


INTERIOR COMPONENTS - CONT'D



REF	PART	DESCRIPTION
1	TIP-2146	DOOR STOP ASSEMBLY
2	T11-0038	DOOR BASKET
3	TIP-2147	FRESH AIR INTAKE
4	TIP-1002	BATTERY
5	T11-0131	LIFTING SUPPORT (ALL CORNERS)

REF	PART	DESCRIPTION
6	T11-S001	FUEL TANK
7	TIP-2148	FABRIC ADAPTER BACKING PLATES
8	TIP-2149	FABRIC ADAPTER


ENGINE SKID ASSEMBLY



REF	PART	DESCRIPTION
1	N/A	GENERATOR - CONTACT STAMFORD
2	N/A	ENGINE - CONTACT KUBOTA
3	TIP-2150	FAN BLOWER ASSEMBLY
3a	TIP-2145	BLOWER BEARING ASSEMBLY
4	T11-S046	LONG RUN TANK
4a	TIP-2058	OIL PAN HEATER
5	T11-0084	HEAT EXCHANGER COVERS
6	T11-S009	HEAT EXCHANGER

REF	PART	DESCRIPTION
6a	T11-S006	HEAT EXCHANGER TO BLOWER ADAPTER
7	TIP-2057	OIL LEVEL SWITCH
7a	TIP-2109	CCV DRAIN LINE
7b	TIP-2115	DIP STICK TUBE
8	TIP-2093	FUEL FILTER, SECONDARY
9	TIP-2111	FUEL FILTER, PRIMARY
9a	TIP-2051	FUEL WATER SEPARATOR - HOUSING & PRIMER
9b	TIP-2100	HEATED FUEL BOWL


ENGINE SKID ASSEMBLY - CONT'D



REF	PART	DESCRIPTION
10	TIP-2096	OIL FILTER (2 REQUIRED)
10a	TIP-2049	DOUBLE OIL FILTER ADAPTER
11	TIP-2010	1/2" NPT PLUG
12	TIP-2142	CCV FILTER
14	TIP-2091	PRIMARY AIR FILTER
14a	TIP-2092	SECONDARY AIR FILTER
15	TI1-0106	RAD SUPPORT ARM
16	TIP-2060	FAN BELT TENSIONER
16a	TIP-2031	ENGINE PULLEY

REF	PART	DESCRIPTION
16b	TIP-2021	BLOWER PULLEY
16c	TIP-2008	TAPERLOCK BUSHING
16d	TIP-2040	BLOWER V-BELT
16e	TIP-2141	ALTERNATOR V-BELT
16f	TI1-0146	BELT GUARD
16g	TI1-0225	TENSIONER BRACKET
16h	TIP-2063	TENSIONER PULLEY
17	TIP-2164	ENGINE TO HEAT EXCHANGER EXHAUST ASSEMBLY
18	TIP-2038	OIL LINES


ELECTRICAL PANEL - EXTERIOR



REF	PART	DESCRIPTION
1	TIP-3008	90 AMP 3 POLE BREAKER
1a	TIP-3002	10 AMP SINGLE POLE BREAKER
1b	TIP-3004	20 AMP SINGLE POLE BREAKER
1c	TIP-3005	30 AMP 3 POLE BREAKER
1d	TIP-3007	60 AMP 3 POLE BREAKER
2	TI1-0229	BREAKER COVER
3	TI1-0126	BLANK BREAKER COVER
4	TIP-3003	LICENSE PLATE LIGHT
5	TIP-3014	CONTROLLER
6	TIP-3013	EMERGENCY STOP BUTTON

REF	PART	DESCRIPTION
7	TIP-1131	SQUARE DOOR LATCH BOLT
8	TIP-6008	WING NUT
9	TIP-3010	MASTER BATTERY DISCONNECT SWITCH
10	TIP-3017	120V GFCI RECEPTACLE
11	TIP-3018	RECEPTACLE 30A-125/250V
11a	TIP-3019	RECEPTACLE 30A-3 PHASE 250V
12	TIP-3041	5 AMP THERMAL BREAKER
12a	TIP-3037	3 AMP THERMAL BREAKER
13	TIP-3069	SSR HEAT SINK


ELECTRICAL PANEL - INTERIOR



REF	PART	DESCRIPTION
14	TIP-3042	BIMETAL THERMOSTAT
15	TIP-3065	PLUG HEATER
16	TIP-3064	PCV SSR 90A
16a	TIP-3068	CONTACTOR 50A
17	TIP-3076	NEUTRAL BLOCK
18	TIP-3096	75mm LONG, DIN RAIL
19	TIP-4025	30 AMP AUTO RELAY
20	TIP-3072	18" LONG PANDUIT & COVER
20a	TIP-3073	10" LONG PANDUIT & COVER
21	TIP-3062	STARTING RELAY
21a	TIP-3060	STARTING RELAY BASE


REF	PART	DESCRIPTION
22	TIP-3038	DUSK/DAWN RELAY
22a	TIP-3039	DUSK/DAWN RELAY BASE
23	TIP-3155	UT 35 TERMINAL BLOCK
24	TIP-3156 TIP-3157	10mm TERMINAL BLOCK & COVER
25	TIP-3056	2.5 MULTI LEVEL TERMINAL BLOCK
26	TIP-3052	2.5 QUATTRO TERMINAL BLOCK
27	TIP-3055	2.5 QUATTRO GROUND TERMINAL BLOCK (GREEN)
28	TIP-3096	250mm LONG, DIN RAIL

LIGHT TOWER




REF	PART	DESCRIPTION
1	TI2-S01	BASE SECTION
1a	TI2-010	PLASTIC GUIDE KIT
1b	TI2-PULLEY1	MAIN CABLE GUIDE WHEEL (2.25" OD)
1c	TIP-4017	MAIN WINCH CABLE
2	TI2-S02	5" TELESCOPIC SECTION
2a	TI2-PULLEY2	SMALL MAIN CABLE GUIDE WHEEL (1.675" OD)
2b	TIP-4018	CABLE TO LIFT 4" SECTION
3	TI2-S03	4" TELESCOPIC SECTION
3a	TIP-4018	CABLE TO LIFT 3" SECTION
4	TI2-S04	3" TELESCOPIC SECTION
4a	TIP-4018	CABLE TO LIFT 2" SECTION
5	TI2-S05	2" TELESCOPIC SECTION
6	TI1-0099	LED TRI LIGHT MOUNT
6a	TI1-0100	COVER
7	TI2-035	PROXIMITY SENSOR PLATE
7a	TIP-4024	PROXIMITY SENSOR
8	TI2-011	ELECTRICAL BOX
8a	TI2-013	COVER
8b	TIP-4025	12V AUTO RELAY
8c	TIP-4021	MAST WINCH SOLENOID
8d	TIP-4020	UP/DOWN SWITCH
9	TIP-4019	WINCH
10	TIP-4012	480W 120V LED ASSEMBLY
	TIP-4022	NYCOIL (NOT SHOWN)
	TIP-4014	BALL BEARING (NOT SHOWN)


LIGHT MAST WIRING DIAGRAM



Exterior Fuel Source Connection



TRAILER WIRING DIAGRAM



BLUE CORD END 7-WAY RV STANDARD

BROWN - RIGHT TURN STOP
BLUE - TRAILER BRAKES
WHITE - GROUND
RED/ORANGE - LEFT TURN STOP
YELLOW - (Not Used) REVERSE LIGHTS.
GREEN - TAIL RUNNING LIGHTS
BLACK - 12V (Not Used) VEHICLE BATTERY

TRAILER WIRING 7-WAY TRADITIONAL

GREEN - RIGHT TURN STOP
BLUE - TRAILER BRAKES
WHITE - GROUND
YELLOW - LEFT TURN STOP
NO CONNECTION CAPPED OFF
BROWN - TAIL RUNNING LIGHTS
NO CONNECTION CAPPED OFF

FILTERS

1. AIR FILTER - INNER
A. DONALDSON - ITEM #P829332
2. AIR FILTER - OUTER
A. DONALDSON - ITEM #P827653
3. ENGINE OIL FILTERS X 2
A. KUBOTA - ITEM #HH160-32430
4. FUEL FILTER - PRIMARY
A. KUBOTA - ITEM #HH1J0-43172
5. FUEL FILTER/WATER SEPARATOR
A. RACOR - ITEM #R60T
6. CCV FILTER
A. KUBOTA - ITEM #1J770-05810

BASECAMP

Toll Free: 1 (855) 554-4344

Email: info@thermalintell.com

Web: thermalintelligence.com/support-content/

Troubleshooting

Field Operations

Maintenance



Scan QR code for support
resources & video library